


AlphaONE-AlphaNANO and AquaBead Instructions

Congratulations

on your new GC TEK Filter



2024 Model Shown



Your <u>clear spring check valve</u> for the AlphaONE bead Agitator is designed so in time (normally many, many years) when the check valve goes out you can simply replace just the valve seat itself in just a few minutes.

Your <u>Multiport valve</u> was carefully chosen to be the least restrictive backwash valve on the market to give maximum flows for the least energy dollars. The internals were carefully designed with maximum flows in mind to give further energy savings, by allowing you to use the most energy efficient pumps on the market.

The AlphaONE <u>Life Support System</u> allows you to hook up a koi pond air pump to the supplied fitting on the front of the multiport valve and supply life giving oxygen to the filter bacteria during times of medical bypass or pump failure.

The GC TEK <u>Bead Agitator</u> is a high quality 2 HP air blower that injects huge amounts of air into the vessel prior to backwash, this breaks up the media pack which allows for a very thorough backwash.

Rest assured that quality was the main consideration when your GC Tek filter was designed and assembled.

Getting to know your GC TEK filter

Heavy Duty Tank Lid Fiberglass Tank Air release valve The vessel is actually a DUAL fiberglass shell. inner shell wrapped over for DUAL Pressure gauge (located on back ath side of Multiport) 2 HP Media Agitator With Switch FROM PUMP Sight Glass WASTE LINE GC TEK **Multiport Valve** Spring check valve "ALISS" Life Support Water drain


Assembly of your Filter



If you have any questions on your filter feel free to give us a call and we'll be glad to help.

405.258.5551

GC Tek Plumbing hook up assembly



Make plumbing hook ups as shown in the picture. Use 2" pipe to connect to unions to secure plumbing to valve.

ALISS Life Support System



Your GC Tek filter addresses the age old problem of "how do I keep my beneficial bacteria from dying when I have to do a medical bypass or I experience pump failure?"

Easy and simple. Just run a line from your koi pond air pump and attach it to the barbed fitting on the front of the multiport valve. Set the Multiport valve to the "RINSE" setting prior to turning on the air pump. Turn on the air pump and the oxygen supplied by the air pump will keep the bacteria happy and safe for several days if necessary. Remember, never run the water pump at the same time that you are running your air pump. It will cause damage to the air pump.

Winterizing the GC Tek Filter

- Turn pump off and drain water from pump basket and volute. If your pump has a drain plug you might find it smart to place the drains plugs in the strainer basket in the pump so you have easy access to them in the Spring when you restart the system.
- 2. Open water drain on filter. No media will come out, only water. Make sure all water is out of filter or damage will occur and this is not covered by warranty.
- Loosen the Multiport valve from the housing and back the valve away from the tank to release any water in the valve.
- 4. Make sure no water is left in the Spring Check valve mounting arm. Turning on the blower briefly will displace the water out of the pipe.

4. Now just wait for Spring.

Backwashing the GC Tek filter



- Turn off water pump. Move Multiport valve to "RINSE". Turn on <u>GC Tek Agitator</u>. Run and cycle Agitator with 20 second on and 5 second off cycles for 5 or 6 cycles. Turn off Agitator.
- 2. While still in the "RINSE" mode, turn water pump on and run until water starts to go out the waste line and then stop water pump.
- 3. Move Multiport valve to "BACKWASH" position, start water pump and run until water is clear in sight glass. Usually 1-3 minutes. Stop pump.
- 4. Move Multiport valve to the "RINSE" position, restart pump and run until water is clear in sight glass. Stop water pump.
- 5. Move Multiport valve to the "FILTER" position and restart the water pump. You're done, it's that simple.

Your GC Tek filter was designed to get rid of the solids when backwashed thus providing you with a more efficient filter and fewer backwashings being needed.

Other settings on your dial are the following:
Waste: Bypasses the filter and sends water to waste.
Recirculate: Bypasses the filter and sends water back to the pond.

Closed: keeps water from going through filter.

IF YOU HAVE QUESTIONS ABOUT YOUR
FILTER
SYSTEM AND NEED HELP, PLEASE CONTACT YOUR DEALER OR
GC TEK AT

405-258-5551 FAX 866-728-0678 INFO@GCTEK.COM

THANK YOU FOR CHOOSING GC TEK



— GARY CRYER